



Items needed to complete flush:

- recirculating bucket
- recirculating pump
- 2 small hoses (example: garden hose)
- motor flush or “ear muffs”
- hose fitting adapter for ear muffs
- **RYDLYME Marine**

Directions to clean an outboard motor:

1. Connect the hose from the bucket to the pump.
2. Connect the second hose from the pump to the “ear muffs” using the hose adapter.
3. Attach the ear muffs to the water inlet of the outboard.
4. Mix **RYDLYME Marine** with 50% water into bucket.
5. Most outboards typically drain from the propeller, but on some models it will drain from the “pee hole”. Make sure the bucket is under the water outlet of the outboard.
6. Circulate solution for approximately 1 hour, depending on the severity of the scale buildup.
7. Dispose of **RYDLYME Marine** down regular sewer system.
8. Flush outboard with fresh water or sea water until it runs clear (5 minutes), to remove any insolubles, like sand.

**IF YOU HAVE ANY
ADDITIONAL QUESTIONS,
CALL ONE OF OUR MARINE
TECHNICIANS AT 800-451-6291.**